























Notice

1 After you get the machine, and check the machine if it is broken and the parts in the list below, any problems, please contact us in 3 days with pictures or videos since you get the machine.

2 Please read the **User Manual** in the SD card.

Item list

Item	QTY	Picture	Note	Item	QTY	Picture	Note
Main equipment	1		Main equipment	Power cable	1		Power cable
Extruder	1		Part	USD Cable	1		USB cable
Extruder fastener	1		Part	Cable tie	5		Tie the cable
Feeding tube	1		Part	Cellophane	2		Clean the linear
Spool holder	1		Part	tweezer	1		Take the model
Winding pipe	1		Part	shovel	1		Take model
Knife	1		Tool	Diagonal pliers	1		Cut cable and take model

Hex tool	5		Tool	SD card	1		SD card
Glass	1		On the hotbed	Card Reader	1		Card reader
Torsion spring	5		Fix the glass	Spare screws	1		Screws
Clamp	5		Fix the glass	knob cap	1		Install to the knob